



The Multi-Trauma dummy offers unique features allowing a variety of interesting training options for more complex scenarios.

1.8M



Model shown here with overall on and off.

A variant of the General Purpose dummy, the Multi-Trauma dummy has the additional feature of a removable right arm and right leg (below the knee) to simulate a partial or complete amputation injury to the victim. Additionally, to simulate a traumatic impalement injury an orifice on the left side of the torso allows a fence post, scaffold pole or similar to penetrate through the dummy and be firmly secured to prevent casual removal.

The shaped head allows the fitting of most types of immobilisation collars. If the head gets badly soiled you can remove the red head cover and wash it.

The body carcass is heavy duty rot-proof canvas with all seams double stitched. High density polypropylene webbing provides extra strength and durability, especially at the high stress points. Machine washable cotton/polyester overalls reinforced with the same webbing are fitted to all sizes of dummy. The ends of the overall arms are further protected with nylon reinforced PVC. Supplied with Wellington boots which also protect the legs if the dummy is dragged along the ground.

A strong webbing loop behind the head helps position and retrieve the dummy, and hang up the dummy to dry after use.

Available in adult size 30kg and 50kg weights.



30 | 50 KG